

4/29/20

FTDX101MP/D Firmware Update Information

Download the FTDX101MP/D [FTDX101_Firmware update_202004.zip] from the following website: https://www.yaesu.com/?cmd=DisplayProducts&DivisionID=65&ProdCatID=102

FTDX101 Firmware update 202004.zip Contains:

- FTDX101_DISPLAY_V0106.SFL
- FTDX101 MAIN V0114.SFL
- FTDX101_IFDSP_V0105.SFL
- FTDX101_SDR_V0203.SFL
- Firmware_Ver_Up_Manual_ENG_FTDX101MP_D_2003-C

Implements improvements

- 1. Implement the network remote control system SCU-LAN10 support.
- 2. Other functions have been improved and optimized.

SD Card Preparation

Refer to FTDX101MP/D Operation Manual (2003A-FS-1) Page 80 [Formatting a SD card].

Formatting a SD card


When using a new SD card, format it according to the following procedure.



Formatting a microSD memory card erases all data saved on it. Before formatting the microSD memory card, be sure to check the data previously saved on it.

- Press the [FUNC] key.
- Select [EXTENSION SETTING] → [SD CARD].
- Touch "DONE" on the "FORMAT" item.
 The format confirmation screen will be displayed.
- Touch "START", the SD card will be initialized.
 Touch "BACK" to cancel the initialization.
- "FORMAT COMPLETED" will be displayed when initialization is completed.
- 6. Touch the screen to end formatting.
- 7. Press the [FUNC] key to exit to normal operation.

After the SD card is formatted and the updated files are installed onto the SD card, it should be displayed like the below image:



If you already have the above firmware versions, it is not necessary to update the FTDX101MP/D again.

We hope this new Firmware will increase your enjoyment of your FTDX101MP/D. Thank you for choosing Yaesu radios. If you have any problems or questions, please contact Yaesu Amateur Tech Support amateurtech@yaesu.com.