

## How to confirm the transceiver's RADIO ID required for new registration of a portable digital node station

Please refer to the following procedure to check the transceiver RADIO ID (5-digit alphanumeric number unique to the transceiver) for new user registration (acquisition of WIRES-X ID number) of WIRES-X portable digital node station.



The transceiver's RADIO ID is a combination of five letters and numbers. Since the RADIO ID is distinguished between uppercase and lowercase letters of the alphabet, please input the RADIO ID displayed on the screen exactly as it is.

- **FT3DR/DE, FT2DR/DE**

- (1) Press and hold **[DISP]** key to open the setup menu.
- (2) Touch **[GM]**.
- (3) Touch **[2 RADIO ID CHECK]**.  
The RADIO ID is displayed.

- **FTM-100DR/DE**

- (1) Press and hold **[DISP(SETUP)]** key to open the setup menu.
- (2) Rotate **DIAL** to select "**6 GM**" and then press **[DISP(SETUP)]** key.
- (3) Rotate **DIAL** to select "**4 RADIO ID CHECK**" and then press **[DISP(SETUP)]** key.  
The RADIO ID is displayed.

- **FTM-300DR/DE**

- (1) Press and hold **[F(SETUP)]** key to open the setup menu.
- (2) Rotate **DIAL** to select "**GM**" and then press **DIAL** knob.
- (3) Rotate **DIAL** to select "**3 RADIO ID CHECK**".  
The RADIO ID is displayed.

- **FTM-400XDR/DE or FTM-400DR/DE**

- (1) Press and hold **[DISP(SETUP)]** key to open the setup menu.
- (2) Touch **[GM]**.
- (3) Touch **[3 RADIO ID CHECK]**.  
The RADIO ID is displayed.